

ML 390/391 Standard

Severity	LED's								Alarm
	Primary Message			Detail Message					
	Menu	Alarm	Sel	10cpi	12 cpi	17 cpi	20 cpi	Prop	
Alarm	Current Mode	On	Off	Current cpi					Paper Out
Alarm	Blink	Off	On	Current cpi					Printhead temperature alarm
Fatal	Off	Blink	Off	On	-	-	-	-	MPU internal error
Fatal	Off	Blink	Off	-	On	-	-	-	Program ROM error
Fatal	Off	Blink	Off	-	-	On	-	-	RAM error
Fatal	Off	Blink	Off	-	-	-	On	-	Spacing Error
Fatal	Off	Blink	Off	-	-	-	-	On	Serial I/F Board error

Additionally

Alarm Name		CPI Led						LQ Led		Font Led	
Classification	Item	10 cpi	12 cpi	15 cpi	17 cpi	20 cpi	Prop	LQ	Util	RES	Card
CPU Alarm	Internal RAM	On	-	-	-	-	-	On	-	-	-
	Serial I/F Connection	On	-	-	-	-	-	-	-	On	-
	Serial I/F Time Out	On	-	-	-	-	-	-	-	-	On
ROM Alarm	Program ROM	-	On	-	-	-	-	On	-	-	-
	Eeprom	-	On	-	-	-	-	-	On	-	-
	Resident ROM	-	On	-	-	-	-	-	-	On	-
	Font Card	-	On	-	-	-	-	-	-	-	On
RAM Alarm	External RAM	-	-	On	-	-	-	On	-	-	-
	RAM Card	-	-	On	-	-	-	-	-	-	On
Mechanical Alarm	Head Homing	-	-	-	On	-	-	On	-	-	-
	Spacing	-	-	-	On	-	-	-	On	-	-
	Print Overrun	-	-	-	On	-	-	On	On	-	-
CG Alarm	Resident ROM	-	-	-	-	On	-	-	-	On	-
	Font Card	-	-	-	-	On	-	-	-	-	On