

## OL 810ex – Level - 1 Menu List

- To enter the MENU set-up please ensure the printer is off-line and then briefly depress the MENU button.
- To enter level 2, please ensure the printer is off-line and then hold the MENU button for 2 seconds.
- Move through the MENU button and when you wish to change an option press ENTER and then the **+** or **-** or the **<>** keys. Press Enter to set.
- When you have finished with the MENU set-up press ONLINE to save and return to printing mode.

<b>Printer language</b>	Emulation	<b>HP4.</b>
<b>Tray select</b>	Manual	<b>Off, On</b>
	Paper In	<b>Tray 1, tray 2, ( if installed) Feeder</b>
	Auto Tray ( if tray 2 installed)	<b>Off, On</b>
<b>Edit size</b>	Edit size	<b>Cassette, Letter, Exec, Legal 14, Legal 13. A4, A5, A6, B5, Com-9, Com-10, Monarch, DL Env., C5 Env., Custom</b>
<b>Paper size</b>	Tray 1	<b>A4, A5, A6, B5, Letter, Exec, Legal 14, Legal 13 (optional tray fitted)</b>
	Tray 2 ( if fitted)	<b>A4, A5, B5, Letter, Exec, Legal 14, Legal 13</b>
	Manual	<b>Letter, Exec, Legal 14, Legal 13. A4, A5, A6, B5, Com-9, Com-10, Monarch, DL Env., C5 Env., Custom</b>
	Tray 2 ( if installed)	<b>A4, A5, A6, B5, Letter, Exec, Legal 14, Legal 13</b>
	Feeder ( if installed)	<b>A4, A5, A6, B5, Com-9, Com-10, Monarch, DL Env., C5 Env., Letter, Exec, Legal 14, Legal 13.</b>
<b>Media Type</b>	Tray 1/ 2	<b>Medium, M Heavy, Heavy, Light, M Light.</b>
	Manual	<b>Medium, M Heavy, Heavy, Light, M Light.</b>
	Feeder	<b>Medium, M Heavy, Heavy, Light, M Light.</b>
<b>Paper Size Check</b>	Size Chk	<b>Enable, Disable</b>
<b>Copies</b>	Copies	<b>1 to 99</b>
<b>Fonts and Symbols</b>	Font Src (Source)	<b>Resident, Card,( if installed) DII Soft ( if loaded)</b>
	Font No.	<b>I000, C000, S0001</b>
	Font CPI ( if scaleable)	<b>10.00, 0.44to 99.99</b>
	Font HGT( if scaleable)	<b>12.00, 4.00 to 999.75</b>
	Symbol (Symbol set)	<b>Roman-8, PC-8, PC-850, IBM-437, IBM-850 Plus many others.</b>
<b>Page Layout 1</b>	A4 Width	<b>78 col., 80 col.</b>
	Blnsksp (Blankskip)	<b>Off, On</b>
<b>Page Layout 2</b>	Orient	<b>Prtrt, Landscp</b>
	Lines/Pg	<b>64 Lines 5 to 128</b>
<b>Host I/F</b>	Host I/f	<b>Auto I/F Parall, RS232C</b>

## Level -2 Menu List

<b>Print Mode</b>	Mode (resolution)	<b>600, 300</b>
<b>Memory Usage</b>	RAST Buf	<b>Auto, 180kb to 3.96 Mb, Ful Ltr, Ful A4, Ful Lgl</b>
	Rec. Buf	<b>Auto,8Kb to 1Mb</b>
	Font Prot	<b>Auto, Off, 100Kb to 3.1MB</b>
	Free Mem	<b>Displayed in Kb</b>
<b>Auto Operation</b>	Autocont	<b>Off, On</b>
	Autoject	<b>Off, On, 5 Secs to 300Secs</b>
<b>Darkness Control</b>	Darkness	<b>0, +1, +2, -2, -1.</b>
<b>Power Saving</b>	Pwr Save	<b>0 Sec, 8 Min Disable</b>
<b>Low Toner</b>	Low Tnr	<b>On, Off</b>
<b>Toner Saving</b>	Toner	<b>Disable, Medium, Light</b>
<b>Clearable Warnings</b>	CLR WRN	<b>On, Job</b>
<b>Parallel I/F</b>	Speed	<b>High, Medium</b>
	BI-Direct	<b>Enable, Disable</b>
	I-Prime	<b>Off, On</b>
<b>RS232/C</b>	Flow Ctl	<b>DTR High, DTR Lo, XON/XOFF, RBST XON</b>
	Baud Rate	<b>9600, 300, 600, 1200, 2400, 4800, 19200.</b>
	Data Bits	<b>8-Bits, 7-Bits</b>
	Parity	<b>None, Even, Odd.</b>
	Min. Busy	<b>200 mS, 1 S</b>
<b>Language</b>	Language	<b>English, German, French, Italian, plus others.</b>

