

OL 400/800 - Level -1 Menu List

- To enter the MENU set-up, please ensure the printer is off-line and then briefly depress the MENU button.
- To enter level 2, please ensure the printer is off-line and then hold the MENU button for 2 seconds.
- Move through the MENU button and when you wish to change an option press ENTER and then the + or - or the < > keys. Press Enter to set.
- When you have finished with the MENU set-up press ONLINE to save and return to printing mode.

Port Selection	Port Select	1, 2, 3 (If Optional I/F fitted)
Printer language	Emulation	HPII, Diablo 630, Proprinter XL
Copies	Copies	1 to 99
Paper Feed	Tray	Tray 1 , tray 2, (if fitted), Manual Feed
Tray size	Tray 1 size	Universal= A4 Universal=A5, Universal=A6, Universal=B5, Envelope=Com, Envelope=Mon, Envelope=DL, Envelope=C5.
	Tray 2 size (if fitted)	Universal= A4 Universal=A5, Universal=A6,
Orientation	Orientation	Portrait , Landscape
Fonts and Symbols	Font Source	Resident , Upper or lower Card,(if installed) Downloaded (if present)
	Font No.	I00 , U00, Upper Card L00, Lower Card S00, Soft Font
	Symbol set	Roman-8 , PC-850, IBM-437, IBM-850 Plus many others.
HP Cartridge	Cart	F , S2, S2-B, S2-F
Page Layout	A4 (80 Chr)	Off=77 col., On=80 col.
Auto Emulation	Auto Emulation	Off , On
Auto Continue	Auto Continue	Off , On

OL 400/800 – Level - 2 Menu List

Interface	Parallel / Serial
I Prime	Off / On
Darkness	-2, -1, 0, +1, +2
Time to quiet	Disable, 1 min, 8 min

Items available in Diablo 630 Mode

Orientation	Portrait , Landscape
Font Source	Resident , Upper Card, Lower Card
Font Select	Font No I00 , U00, L00
Pitch	10cpi , 12cpi, 15cpi, Prop
ASCII Mode	7 Bit , 8 Bit
Auto LF	Off , On
Auto CR	Off , On
Auto Emulation	Off , On
Auto Tray	Off , On
Auto Continue	Off , On

Items available in IBM Proprinter Mode

Orientation	Portrait , Landscape
Pitch	10cpi , 12cpi, 15cpi, Prop
Emphasized	Off , On
Double Height	Off , On
Double Width	Off , On
Symbol set	IBM set2 , set3, set4
Line Length	80 , 136
Slash Zero	Off , On
Slash Letter O	Off , On
Form Length	12 , 11
Auto LF	Off , On
Auto CR	Off , On
Auto Emulation	Off , On
Auto Tray (if second tray fitted)	Off , On
Auto Continue	Off , On